

Série RC, accessoires pour vérins



▼ TABLEAU DE SÉLECTION





A utiliser avec vérin capacité tonnes (kN)	Têtes			Plaque de base	Bloc de montage	Raccord à chape	
	Lisse	Striée ¹⁾	Oscillante			Base ⁴⁾	Piston
							
5 (45)	A-53F ²⁾	A-53G ²⁾	–	–	RB-5 ²⁾ , AW-51 ²⁾ , AW-53 ²⁾	REB-5 ²⁾	REP-5 ²⁾
10 (101)	A-12 ³⁾ , A-102F ³⁾	A-102G ³⁾	CAT-10 ³⁾	JB1-10	RB-10, AW-102	REB-10	REP-10 ³⁾
15 (142)	–	A-152G	CAT-10	–	RB-15	REB-15	REP-10
25 (232)	A-29 ⁵⁾	A-252G	CAT-50	JB1-25	RB-25	REB-25	REP-25
30 (295)	A-29 ⁵⁾	A-252G	CAT-50	–	RB-25	–	REP-25
50 (498)	–	–	CAT-100	JB1-50	–	–	–
75 (718)	–	–	CAT-100	–	–	–	–
95 (933)	–	–	CAT-100	–	–	–	–



¹⁾ Standard sur vérin RC 5 à 30 tonnes ²⁾ Excepté RC-50 ³⁾ Excepté RC-101 ⁴⁾ Vis de montage comprises ⁵⁾ Utilisé avec ensembles de cintrage

▼ TABLEAU DES DIMENSIONS

Référence	Dimensions des têtes (mm)			A-53F, A-102F A-12, A-29	Référence	Dimensions têtes oscillantes (mm)			
	A	B	C			A	B	C	
	Lisses					Oscillantes			
A-53F	25	6	17		CAT-10	35	15	22	
A-102F	35	6	22		CAT-50	50	23	35	
A-12	51	48	1"-8UNC						
A-29	51	48	1 1/2"-16UNC						
	Striées				CAT-100	71	24	–	
A-53G	25	6	17						
A-102G	35	6	22						
A-152G	38	9	22						
A-252G	50	9	35						

Référence	Dimensions plaque de base (mm)					
	A	B	C	D	E	
JB1-10	228	228	135	58	20	
JB1-25	279	279	140	86	26	
						
JB1-50	304	15	95	131	31	

Référence	Dimensions blocs de montage (mm)								
	A	B	C	D	E	F	G	H	
RB-5	1 1/2" - 16	88	76	–	25	–	–	–	
AW-51	1 1/2" - 16	70	59	10	24	54	1/4" - 20	41	
AW-53	1 1/2" - 16	72	7	7	19	57	1/4" - 20	10	
RB-10	2 1/4" - 14	114	88	–	25	–	–	–	
AW-102	2 1/4" - 14	100	82	16	30	76	7/16" - 20	58	
RB-15	2 3/4" - 16	101	114	–	38	–	–	–	
RB-25	3 5/16" - 12	127	165	–	50	–	–	–	

Type	Référence	Dimensions raccords à chape (mm)						
		A	B	C	D	E	F	
Base ⁴⁾	REB-5	44	47	14	16	16	25	
	REB-10	63	66	25	22	25	35	
	REB-15	76	66	25	22	25	35	
	REB-25	95	79	38	31	31	41	
Piston	REP-5	28	41	14	16	16	19	
	REP-10	42	61	25	22	25	28	
	REP-25	57	74	38	31	31	35	

i Pour l'utilisation de ces accessoires voir nos 'Pages Jaunes'.