














PX4000 Maintenance Kit BOM



No.	Product Model	Pramac Kit Code	Pramac Individual Code	Part Description	Part Picture	QTY
1	PX4000	P3KI00550	PAA00500	SPARK PLUG		1
2			TBA	ELEMENT, AIR FILTER		1
3			TBA	FUEL PIPE $\Phi 7^* \Phi 13^* 290$		1
4			PAA00142	FILTER, FUEL TANK		1
5			PAA00104	CARBON BRUSH		1
6			MKB	Maintenance kit Box		1






PX8000 Maintenance Kit BOM



No.	Product Model	Pramac Kit Code	Pramac Individual Code	Part Description	Part Picture	QTY
1	PX8000	P3KI00551	PAA00500	SPARK PLUG		1
2			TBA	ELEMENT 1#, AIR FILTER		1
3			TBA	ELEMENT 2#, AIR FILTER		1
4			TBA	FUEL PIPEΦ13*Φ7*85		1
5			TBA	FUEL PIPEΦ13*Φ7*345		1
6			PAA00142	FILTER, FUEL TANK		1
7			PAA00104	CARBON BRUSH		1
8			MKB	Maintenance kit Box		1

P2200i Maintenance Kit BOM



No.	Product Model	Pramac Kit Code	Pramac Individual Code	Part Description	Part Picture	QTY
1	P2200i	P3KI00552	PGT97101	Spark Plug		1
2			TBA	Element Air Cleaner		1
3			TBA	Screen		1
4			PGT516401	Filter Fuel		1
5			MKB	Maintenance kit Box		1